


From February 1st, 2017 SAMES Technologies SAS becomes SAMES KREMLIN SAS  
A partir du 1/02/17, SAMES Technologies SAS devient SAMES KREMLIN SAS

**SAMES**  **KREMLIN**



# User manual

## Magnetic Bellcups and Shaping air assemblies used with High Speed Turbine

FRANCE

**SAMES Technologies.** 13 Chemin de Malacher 38243 Meylan Cedex  
Tel. 33 (0)4 76 41 60 60 - Fax. 33 (0)4 76 41 60 90 - [www.sames.com](http://www.sames.com)

USA

**Exel North America.** 45001 5 Mile Road, Plymouth, Michigan, 48 170  
Tel. (734) 979-0100 - Fax. (734) 927-0064 - [www.sames.com](http://www.sames.com)

All communication or reproduction of this document, in any form whatsoever and all use or communication of its contents are forbidden without express written authorisation from SAMES Technologies.

The descriptions and characteristics mentioned in this document are subject to change without prior notice.

© SAMES Technologies 2005



**WARNING :** SAS Sames Technologies is registered with the Ministry of Labour as a training institution.

Throughout the year, our company offers training courses in the operation and maintenance of your equipment.

A catalogue is available on request. Choose from a wide range of courses to acquire the skills or knowledge that is required to match your production requirements and objectives.

Our training courses can be delivered at your site or in the training centre at our Meylan head office.

**Training department:**

**Tel. 33 (0)4 76 41 60 04**

**E-mail: [formation-client@sames.com](mailto:formation-client@sames.com)**

**SAS Sames Technologies** operating manuals are written in French and translated into English, German, Spanish, Italian and Portuguese.

The French version is deemed the official text and Sames will not be liable for the translations into other languages.

Magnetic Bellcups and Shaping air assemblies used with High Speed Turbine


1. Recommendations - - - - -	4
2. Description - - - - -	4
3. Characteristics - - - - -	5
4. Installation - - - - -	5
5. Maintenance- - - - -	6
5.1. <i>Magnetic Bellcup</i> . . . . .	6
5.1.1. <i>Removal.</i> . . . . .	6
5.1.2. <i>Reassembly</i> . . . . .	7
5.2. <i>Shaping air assembly</i> . . . . .	8
5.2.1. <i>Disassembly.</i> . . . . .	8
5.2.2. <i>Reassembly</i> . . . . .	8
6. Cleaning- - - - -	9
6.1. <i>Bellcup cleaning</i> . . . . .	9
6.2. <i>Deflector cleaning</i> . . . . .	10
6.3. <i>Outer cover cleaning</i> . . . . .	11
7. Spare parts- - - - -	12
7.1. <i>Frequency of Bellcup replacement</i> . . . . .	12
7.2. <i>EC 35 magnetic Bellcup</i> . . . . .	12
7.3. <i>EC 50 magnetic Bellcup</i> . . . . .	13
7.4. <i>EC 65 Magnetic Bellcups</i> . . . . .	14
7.4.1. <i>EC 65 aluminium magnetic Bellcup.</i> . . . . .	14
7.4.2. <i>EC 65 titanium magnetic Bellcup.</i> . . . . .	14
7.5. <i>EC 80 Magnetic Bellcup</i> . . . . .	15
7.6. <i>Shaping air assembly associated to the EC 35 magnetic Bellcup</i> . . . . .	16
7.7. <i>Shaping air assembly associated to the EC 50 magnetic Bellcup</i> . . . . .	17
7.8. <i>Shaping air assembly associated to the EC 65 magnetic Bellcup</i> . . . . .	18
7.8.1. <i>45° shaping air assembly.</i> . . . . .	18
7.8.2. <i>0° Shaping air Assembly</i> . . . . .	19
7.9. <i>Shaping air assembly associated to the EC 80 magnetic Bellcup</i> . . . . .	20
8. Specific tools - - - - -	21
8.1. <i>Common tool</i> . . . . .	21
8.2. <i>For removal and fitting the different bellcups</i> . . . . .	21

## 1. Recommendations

For perfect results, the atomizing bellcup must be cleaned frequently. It is recommended to clean the bellcup external every 8 hours and completely every 120 hours. The bellcup must not be subjected to impacts on its atomizing edge or distorted because it is balanced.

### Necessary Checks:

It is imperative to check the wear of the bellcups (diameter 35, 50, 65 and 80) at the level of the spraying edge every 120 hours using a binocular 50-times magnifying glass.



**WARNING :** If these recommendations are not respected, the operator exposes himself to the mechanical risk characterized by a tearing of the material due to the excessive wear of the bellcup.

For the frequencies of the various bellcups replacement ([see § 7.1 page 12](#)).


## 2. Description

The bellcup is a component which allows the atomizing of liquid materials specially high solid primers, basecoats and clearcoats. A specific bellcup design is selected for the type of product being sprayed.

Bellcups are fixed to the high speed turbine ST by a magnetic device.

With each diameter of bellcup corresponds one or more assembly of shaping air ring.

### Example: EC 65 and 80 Bellcups



### 3. Characteristics

	<b>Magnetic Aluminium Bellcup</b>	<b>Magnetic Aluminium Bellcup</b>	<b>Magnetic Aluminium Bellcup</b>	<b>Magnetic Titanium Bellcup</b>	<b>Magnetic Aluminium Bellcup</b>
Diameter	35 mm	50 mm	65 mm	65 mm	80 mm
Length	45.5 mm	45.5 mm	45.5 mm	45.5 mm	45.5 mm
Weight	38 g	44 g	49 g	49,5 g	50 g

### 4. Installation

[see § 5.1.2 page 7](#) and [see § 5.2.2 page 8](#).

## 5. Maintenance



**WARNING :** Before any operation, stop shaping air and high voltage and wait for a complete stop of the turbine. Never stop the bearing air.

### 5.1. Magnetic Bellcup



**WARNING :** All maintenance and handling operations operated on the bellcup must be carried out with utmost care as it is balanced.




**WARNING :** Any use of an unbalanced bellcup involves an inevitable destruction of the high speed turbine. Possible causes for unbalanced rotating parts are: paint deposits, physical damage and dry paint located on the bellcup or on the securing cone.

#### 5.1.1. Removal



**WARNING :** The magnetic bellcup removal is carried out only the shaping air assembly in place.

- **Step 1:** Position the tool ([see § 8 page 21](#)), side of small diameter against the outer cover.
- **Step 2:** Close the tool on the bellcup and pull the bellcup in the axis.
- **Step 3:** Maintain the tool supporting the bellcup in order not to let it fall. Place the bellcup on a plane and perfectly clean surface.






## 5.2. Shaping air assembly

The procedure is identical whatever the diameter of the bellcup and whatever the type of the shaping air assembly.

Item	Description
1	O-ring
2	Shaping air shroud
3	Outer cover



### 5.2.1. Disassembly

- **Step 1:** With the fingers, push the shaping air shroud against the atomizer and remove the outer cover using the tool (P/N # 1308689) by placing the wrench notches into the outer cover slots, turn clockwise and continue removing by hand.
- **Step 2:** Remove the shaping air shroud.

### 5.2.2. Reassembly



**WARNING :** Clean all components and inspect for damage, replace if necessary [see § 7 page 12](#).

- **Step 1:** Check the presence of the o-ring on the shaping air shroud, install it on the atomizer while making corresponding the various indexes (see illustration) and put it in stop.
- **Step 2:** Put in place the outer cover over the assembly, secure it by hand then tighten it with the tool P/N # 1308689.






## 6. Cleaning

### 6.1. Bellcup cleaning




**WARNING :** All maintenance and handling operations operated on the bellcup must be carried out with utmost care as it is balanced.

- **Step 1:** Remove the bellcup ([see § 5.1.1 page 6](#)).
- **Step 2:** Leave to soak in solvent for one hour then clean with a clean cloth and soft brush.



- **Step 3:** Dry carefully the two faces of the bellcup as well as the fixing cone with compressed air.




## 6.2. Deflector cleaning

- **Step 1:** Remove the deflector, ([see § 5.1.1.1 page 7](#)).

- **Step 2:** Leave to soak in solvent for one hour.

- **Step 3:** Then clean with a clean cloth and soft brush.

- **Step 4:** Dry carefully the two faces of the deflector with compressed air.




DES02825

### 6.3. Outer cover cleaning


- **Step 1:** Remove the outer cover, [see § 5.2.1 page 8](#).

1	Outer cover
2	Shaping air shroud
3	O-ring



DES02817

- **Step 2:** Leave to soak in solvent the outer cover for one hour, then clean the outer and inner surfaces using a rag soaked in solvent.
- **Step 3:** Using a nylon brush, clean all the holes located on the front face of the outer cover.
- **Step 4:** Dry carefully with compressed air insisting on the holes to eliminate the paint residues, then wipe with a clean dry rag.
- **Step 5:** Check the shaping air shroud, clean it if necessary using a rag soaked in solvent.



DES02818

## 7. Spare parts

Note: These bellcups can be installed only on high speed turbine ST.



**WARNING** : The deflector removal is an operation to be only with an aim of cleaning, the deflector is balanced with the bellcup and thus cannot be replaced alone.


### 7.1. Frequency of Bellcup replacement

Types of bellcups	Replacement frequency
EC 35 bellcup	5000 hours
EC 50 bellcup	5000 hours
EC 65 bellcup	5000 hours
EC 80 bellcup	2500 hours




**WARNING** : Sames Technologies recommends to integrate these periodicities in preventive maintenance schemes and to systematically apply them, so that the equipment is not affected by an excessive wear of the bellcup.

### 7.2. EC 35 magnetic Bellcup



Item	Part number	Description	Qty	Sale unit	First Priority	Wear
	<b>910000636</b>	<b>EC 35 aluminium magnetic bellcup</b>	<b>1</b>	<b>1</b>	<b>X</b>	
1	J3STKL094	O-ring - chemically inert	1	1		X

### 7.3. EC 50 magnetic Bellcup




DES03692

Item	Part number	Description	Qty	Sale unit	First Priority	Wear
	<b>910003159</b>	<b>EC 50 aluminium magnetic bellcup</b>	<b>1</b>	<b>1</b>	<b>X</b>	
1	J3STKL094	O-ring - chemically inert	1	1		X


## 7.4. EC 65 Magnetic Bellcups

### 7.4.1. EC 65 aluminium magnetic Bellcup




Item	Part number	Description	Qty	Sale unit	First Priority	Wear
	<b>910000635</b>	<b>EC 65 aluminium magnetic bellcup</b>	<b>1</b>	<b>1</b>	<b>X</b>	
1	J3STKL094	O-ring - chemically inert	1	1		X

### 7.4.2. EC 65 titanium magnetic Bellcup



Item	Part number	Description	Qty	Sale unit	First Priority	Wear
	<b>910000672</b>	<b>EC 65 titanium magnetic bellcup</b>	<b>1</b>	<b>1</b>	<b>X</b>	
2	J3STKL094	O-ring - chemically inert	1	1		X

## 7.5. EC 80 Magnetic Bellcup



Item	Part number	Description	Qty	Sale unit	First Priority	Wear
	<b>910000600</b>	<b>EC 80 aluminium magnetic bellcup</b>	<b>1</b>	<b>1</b>	<b>X</b>	
1	J3STKL094	O-ring - chemically inert	1	1		X


  

Item	Part number	Description	Qty	Sale unit	First Priority	Wear
	<b>910006759</b>	<b>EC 80 aluminium treated magnetic bellcup</b>	<b>1</b>	<b>1</b>	<b>X</b>	
1	J3STKL094	O-ring - chemically inert	1	1		X

Item	Part number	Description	Qty	Sale unit	First Priority	Wear
	<b>910003730</b>	<b>EC 80 aluminium magnetic bellcup</b>	<b>1</b>	<b>1</b>	<b>X</b>	
1	J3STKL094	O-ring - chemically inert	1	1		X

### 7.6. Shaping air assembly associated to the EC 35 magnetic Bellcup




DES03593

Item	Part number	Description	Qty	Sale unit	First Priority	Wear
	<b>910003193</b>	<b>45° shaping air assembly, EC 35 Bellcup, High speed turbine</b>	<b>1</b>	<b>1</b>	<b>X</b>	
1	J2FENV622	O-ring	1	1		X
2	900001005	Shaping air shroud	1	1		X
3	900001006	Vortex outer cover	1	1	X	




### 7.7. Shaping air assembly associated to the EC 50 magnetic Bellcup



Item	Part number	Description	Qty	Sale unit	First Priority	Wear
	<b>910003192</b>	<b>45° shaping air assembly, EC 50 Bell-cup, High speed turbine</b>	<b>1</b>	<b>1</b>	<b>X</b>	
1	J2FENV622	O-ring	1	1		X
2	900002470	Shaping air shroud	1	1		X
3	900002469	Vortex outer cover	1	1	X	

## 7.8. Shaping air assembly associated to the EC 65 magnetic Bellcup


### 7.8.1. 45° shaping air assembly



DES02806

Item	Part number	Description	Qty	Sale unit	First Priority	Wear
	<b>910000674</b>	<b>45° shaping air assembly, EC 65 Bell-cup, High speed turbine</b>	<b>1</b>	<b>1</b>	<b>X</b>	
1	J2FENV622	O-ring	1	1		X
2	900000569	Shaping air shroud	1	1		X
3	900000570	45° Vortex outer cover	1	1	X	


7.8.2. 0° Shaping air Assembly



DES02805

Item	Part number	Description	Qty	Sale unit	First Priority	Wear
	<b>910000856</b>	<b>0° shaping air assembly, EC 65 Bellcup, High speed turbine</b>	<b>1</b>	<b>1</b>	<b>X</b>	
1	J2FENV622	O-ring	1	1		X
2	900000569	Shaping air shroud	1	1		X
3	900000577	0° Vortex outer cover	1	1	X	


**7.9. Shaping air assembly associated to the EC 80 magnetic Bellcup**



Item	Part number	Description	Qty	Sale unit	First Priority	Wear
	<b>910000673</b>	<b>55° Vortex shaping air assembly, EC 80 bellcup , high speed turbine</b>	<b>1</b>	<b>1</b>	<b>X</b>	
1	J2FENV622	O-ring	1	1		X
2	900000106	Shaping air shroud	1	1		X
3	900000108	55° Vortex outer cover	1	1	X	


## 8. Specific tools

### 8.1. Common tool



Part number	Description	Qty	Sale unit
1308689	Outer cover fitting / removal wrench	1	1

### 8.2. For removal and fitting the different bellcups



Part number	Description	Qty	Sale unit
900000804	Removal tool for EC 35 magnetic bellcup	1	1
900000803	Removal tool for EC 50 magnetic bellcup	1	1
1204427	Removal tool for EC 65 magnetic bellcup	1	1
1204556	Removal tool for EC 80 magnetic bellcup	1	1